


WGWAG™ FIN INSTALLATION

YOU WILL NEED A PHILLIPS HEAD SCREWDRIVER OR DRILL.

Read the directions all the way through as you only have 10 minutes before the Loctite hardens.
(We use Loctite Thread Locker Blue 242 Removable.)


DIRECTIONS




1. Flip WGWAG so legs are facing up.
Work on one fin at a time.
Long edge of fin is on the outside edge of the WGWAG.

THREADED INSERT

2. Shake and squeeze Loctite into the 4 threaded inserts in 2 adjacent legs on one side of the WGWAG.
(Safety warnings for Loctite are on product packaging.)



3. Place the fin on top of holes and put a washer over each hole. You may have to push legs together slightly to align the holes.
4. Put a squeeze of Loctite on the shaft of each screw before inserting. Tighten down.



COMPLETED.

5. Repeat for second fin.
6. Let cure for 24 hours.

If you need space for storage, at season's end, pop the seal with a hand tool. Save the screws and washers in a bag taped to the deck. Remove fins and stack boats. Repeat at the start of next season.

Additional Removable Loctite is available at Home Depot and on Amazon.



WAYS TO CARRY



- Tighten the drain plug. The WGWAG ships with drain plug loosened.
- Attach the tether rope to handle by slipping the line through the loop and keep it affixed at all times.
- Wear a Coast Guard-approved personal flotation device (PFD) for any water activity. Safety first!

HOW TO WGWAG™


DIRECTIONS

- Start in calm water.
- Push WGWAG out sufficient water depth to clear fins.
- Grab sides, step on.
- Place feet slightly wider than shoulder-width and even with the side pockets.
- Shift weight left to right between your two feet.
- Grab rope and use for balance, as needed.



HEELS ON THE SMALL Ws.

WITH WGWAG IN MOTION



CONTINUE TO SHIFT WEIGHT FROM LEFT TO RIGHT. THE FASTER YOU GO, THE EASIER IT IS TO TURN.



TURN BY SLIGHTLY MOVING FEET ON THE DECK.

THE WGWAG IS A DURABLE, PLASTIC BOAT. FOR YOUR SAFETY AND ENJOYMENT, CONTROL ITS MOVEMENT AND BE AWARE OF OTHERS NEARBY.

SAFETY

- DO NOT**
- use the WGWAG beyond your skill level or ability
 - use in waves, strong currents, rapids, or inclement weather
 - tow behind any powered watercraft
 - use for any purpose other than flotation on water
 - exceed the maximum capacity of **225 lbs**
 - Permit more than one person on WGWAG.

- ALWAYS**
- wear a Coast Guard-approved personal flotation device and stay within swimming distance of shore
 - supervise minors on a WGWAG.
 - follow the manufacturer's recommendations for use of the WGWAG

NOTE

FOR 1 PERSON
(225 LB MAX)

DO NOT FLIP



DO NOT TOW BEHIND
MOTORIZED WATERCRAFT



CARE & MAINTENANCE

WGWAG are made of durable polyethylene plastic, LDPE, which is virtually maintenance-free. A minimal amount of care in storage and transport will help the WGWAG maintain a like-new condition for many years.

Polyethylene may become more flexible under hot sun. This will not harm your WGWAG or its functionality. There is UV protection built into the plastic hull and the pad; however, we recommend keeping your WGWAG out of direct sunlight or covered when not in use to prevent premature fading.

At the start of the season, you can extend the UV life of the color and improve the brightness and shine with a few squirts of a protectant like 303[®] Aerospace Protectant[™].